2901 Airport Drive, Torrance, California 90505

Phone (310) 539-0508 Fax (310) 539-5198

KI-205 Ground Handling Cart Booster Cable Kit Instructions

NOTE

Visit <u>www.robinsonheli.com</u> to verify kit instructions are current revision. Review instructions before installation; contact RHC Technical Support with questions. Verify kit contents match list; contact RHC Customer Service if parts are missing or damaged.

ITEM	PART NUMBER	DESCRIPTION	QTY PER KI-205
		KIT CONTENTS	
1	KI-205 INSTR.	Kit Instructions	1
2	MS35489-22	Grommet	1
3	MT949-1	Cable Assembly	1
4	MT949-2	Cable Assembly	1
5	MT956-1	Hanger	2
6	2703	Hole plug	2
7	9764K47	Bumper	2

Kit Instructions

NOTE

MT900 Ground Handling Cart Manual and MT950 Ground Handling Cart Manual are available online.

NOTE

KI-205 installation is identical for MT900 and MT950 ground handling carts.

- 1. Turn ground handling cart power switch OFF.
- Refer to Figure 1. Install one 9764K47 bumper and one 2703 hole plug on each MT956-1 hanger as shown. Position hangers slot-down and centered on aft ridges of MT901-1 frame weldment at locations shown. Using a soft mallet, tap hangers onto frame until bottomed.
- 3. Remove and discard hole plug from MT931-1 cover, if installed. If no hole is present, cut 1.25-inch dia. hole in cover at location shown. Install MS35489-22 grommet.
- 4. Refer to Figure 2. Open access doors and route MT949-2 cable assembly through grommet until stripeless wire reaches forward battery negative lug.

Issued 01 NOV 2011 By Lindsay Allen Page 1 of 4
Revision A Approved Pat Cox Ground Handling Cart Booster Cable Kit

2901 Airport Drive, Torrance, California 90505

Phone (310) 539-0508 Fax (310) 539-5198


Kit Instructions (continued)


- 5. Disconnect ground wire from forward battery negative lug.
- 6. Connect existing copper strap and MT949-2 cable assembly red-striped wire to aft battery positive lug. Torque terminal as noted on battery label.
- 7. Connect ground wire and MT949-2 cable assembly stripeless wire to forward battery negative lug. Torque terminal as noted on battery label. Close access doors.
- 8. Connect MT949-1 and MT949-2 cables together and wrap over hangers.

Issued 01 NOV 2011 Page 2 of 4

2901 Airport Drive, Torrance, California 90505

Phone (310) 539-0508 Fax (310) 539-5198









FIGURE 1

Issued 01 NOV 2011 Page 3 of 4



Issued 01 NOV 2011

Page 4 of 4